



# Sony Ericsson z300 Back Dark Grey Case Replacement

Remove the case in order to access the Motherboard.

Written By: Alex Serventi



## INTRODUCTION

This guide will show you how to remove the Dark Grey case that allows you access to the Motherboard.

---



### TOOLS:

- [T5 Torx Screwdriver](#) (1)
-

## Step 1 — Back Phone Cover



- To remove the back cover, use your thumb to press down on the center of case and slide it off.

## Step 2 — Battery



- Using a fingernail lift the battery out of the phone.



## Step 3 — Sim Card



- Slide the sim card out with your thumb.


## Step 4 — Back Dark Grey Case



- To remove the back case first remove the four screws shown with a T5 Torx screwdriver




## Step 5



- Using your fingernail lift up the side of the casing around the bottom of the phone to release all five of the clips.

## Step 6



- Lift up towards the bottom and slide the case off.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 06:58:32 PM.